

(A) How to change the charger plate

Part I: Release the charger plate



Step 1:

Press and hold the lock button to release the interchangeable charger plate.



Step 2:

Pull the released interchangeable charger plate out of the slot.



Step 3:

Take the interchangeable charger plate out.

Part II: Install the new charger plate



Step 1:

Attach the selected interchangeable charger plate onto the charger base from the top into the slots.



Step 2:

Push the interchangeable charger plate fully in the direction as shown in the above diagram.



Step 3:

The interchangeable charger plate is fully inserted into the charger base only when you hear the sound "click".